



QUICKCHANGE[®]

URINE MANAGEMENT WRAP

800.206.2816
quickchange.com



Change
in 60
Seconds

Prevents CAUTI and Pressure Injuries

Replaces catheters and other
external urine collection devices

Superabsorbent Core

Locks in moisture and holds
more than 500mL

Unique Shape

Wraps around the
penis so urine never
touches the skin



PATIENT PROFILE:

This product is primarily
for minimally ambulatory,
bedbound, or chairbound men

WHY QUICKCHANGE WRAPS?

Changing a wrap takes 60 seconds
regardless of a man's size, anatomy,
or weight

ADDITIONAL USES

- **COVID:** Allows patients to self change themselves and supports overall infection prevention goal of less contact
- **CDIFF:** Use to create a physical barrier between urinary catheters and bowel movements (females included)
- **Ostomy stomas/fecal management:** Easily wraps around and over stomas to help manage output during cleansing and preparation for new patches/pouches/bags as well as aiding the absorption and reduction of leakage
- **Intermittent urine management:** Situations without access to restrooms (pre/post-op, imaging, dialysis, hyperbaric treatments, rehab, etc)
- **Skin irritation/perspiration:** Use as an absorbent layer in between gastric folds or inframammary folds under breasts



Prevents
CAUTI & HAPI



Replace
Caths & Briefs



Promotes
Skin Health



Works With
Briefs/Diapers



Holds
>500mL



No Lifting
Required



Decrease
Fall Risks



Minimize Sleep
Interruptions

SCAN US

For easy-to-follow video instruction
Call to schedule a no-obligation in-service at 800-206-2816



BROCHURE &
OUTCOMES



DIRECTIONS
FOR USE



PRE-RECORDED
IN-SERVICE




INPUTS &
OUTPUTS




DIRECTIONS FOR USE

Standard Penis: Low Urine Pressure (1 wrap)



Place white side up, round edge towards head, and two flaps towards legs.




Fold pointed flap over penis at 45°, then fold straight flap over, slightly pulling upwards.




With two fingers, pinch hook fastener and inner flap together to ensure attachment.

Standard Penis: Strong Urine Pressure (2 wraps)



Follow steps 1-3 above. Place 2nd wrap underneath and 3-4" higher than 1st wrap.




Pull the top center of the 2nd wrap down and over the 1st wrap, just to the right of center.




Lift the straight flap up and over towards the center, pinching the hook fastener to secure.


Retracted/Indwelled Penis (1 wrap)



Place white side up, round edge towards head, two flaps pointed towards legs.



Slide pointed flap underneath scrotum, lift and scoop upwards and then fold straight flap over.




Pinch hook fastener and inner flap together to ensure attachment.

Bariatric: Hidden/Covered Penis (2 wraps)



Place underneath the scrotum, pull towards head to ensure contact, tuck between the legs to catch runoff.




Place a 2nd wrap, white side up, over belly so that source of the urine is visible through the center opening. Fold hook flap.




Fold the 2nd wrap in half downwards and lengthwise, making sure the center hole is adequately covered.


Scrotal Edema: Medium (1 wrap)



Place white side up, round edge towards head, two flaps towards legs.




Pull pointed flap underneath scrotum creating bowl shape and pull straight flap over.




Pinch hook fastener and inner flap together to ensure attachment.


Scrotal Edema: Large (2 wraps)



Position two wraps around scrotum & penis; pinch & secure a straight and a pointed flap together as a fulcrum.




Pull other two flaps towards each other, starting a bowl shape underneath scrotum & pinch two flaps together.




Readjust and tighten the flaps repeatedly, completing the bowl shape. Ensure good contact under scrotum.

DO NOT...



Roll into a tight, cone/funnel shape.



Leave the QuickChange pointed towards the legs.